by minkaAire

# CITY CONTEMPO™

BY

kathy ireland HOME®

GALLERY

U.S. Patents: D598,999; D599,003; D599,459

*INSTRUCTION MANUAL WARRANTY CERTIFICATE*

This product is protected by United States Federal and/or State Law, including Patent, Trademark and/or Copyright laws.
Manual design and all elements of manual design are protected by U.S. Federal and/or State Law, including Patent, Trademark and/or Copyright laws.

**Minka-Aire® warrants to the original owner that this fan will be free from defects in material and workmanship for one year from the date of purchase, excluding the motor. Minka-Aire® warrants to the original owner that the motor in this fan shall be free from defects in material and workmanship for as long as the original purchaser owns the fan, and it remains in the original installation.**

**This is a limited warranty. Minka-Aire's ® only obligation under this limited warranty is to replace or repair, or refund the purchase price, in Minka-Aire's® sole discretion without charge to the original owner, of the fan once Minka-Aire® confirms that the fan has a defect covered by this limited warranty.**

**Call our customer service department at 1-800-307-3267 to obtain the name of the Minka-Aire® authorized dealer closest to your location, or contact us through our web site, www.minkagroup.net and write to: Ask Mr. Minka if you have any questions or require further assistance.**

**To obtain warranty service, the owner should return the fan along with proof of purchase to a Minka-Aire® authorized dealer. The Minka-Aire® authorized dealer shall then, at its sole discretion: repair the fan, replace the fan, refund the purchase price less the amount directly attributable to the consumer's prior usage of the fan, or if necessary instruct the consumer to contact Minka-Aire® directly for warranty service. Minka-Aire® will be responsible for the cost of any repair, or replacement for any warranty service provided by a Minka-Aire® authorized dealer for product under warranty.**

**You may also at your preference obtain warranty service by returning the fan directly to Minka-Aire® along with proof of purchase, your name and return address, and a description of the claimed product defect. Pack carefully; damage sustained in return transit to Minka-Aire® will be the original owner's responsibility. Original owner shall be responsible to pay all shipping charges. To obtain warranty service, you may return a fan that proves to be defective during the warranty period to the following address:**

**Minka-Aire® - Warranty Service, 1151 W. Bradford Court, Corona, CA 92882**

**This warranty shall not apply to fans which have been damaged in any way, including improper installation, damage as a result of the removal of the fan from the origial installation, or damage in shipping. This warranty shall not apply to fans which have been subjected to use for which the fan was not designed. The purchaser of the fan shall be responsible for any cost of removing the old fan, installing a new fan, or any other costs.**

**This limited warranty is in lieu of all other express warranties. This limited warranty excludes all incidental and consequential damages, and Minka-Aire® shall not under any circumstances be liable for incidental or consequential damages. Some States do not allow the exclusion of or limitation of incidental or consequential damages, so the foregoing limitation or exclusion may not apply to you.**

**This warranty gives you specific legal rights, and you may also have other rights which vary from State to State. We encourage you to promptly complete and return the enclosed warranty registration card. However, return of the warranty registration card is not a condition of this warranty.**

**Date Purchased** _____ **Store Purchased** _____ **Model Number** F679 **Serial Number** _____

# CONTENTS


SAFETY RULES..... 1
PACKAGE CONTENTS..... 2
INSTALLING THE FAN..... 3
HANGING THE FAN..... 4
ELECTRICAL CONNECTIONS..... 5
INSTALLING THE WALL TRANSMITTER..... 6
FINISHING THE INSTALLATION..... 7
BLADE INSTALLATION..... 8
INSTALLING THE MOTOR HOUSING..... 9
INSTALLING THE LIGHT PLATE..... 10
INSTALLING THE LIGHT BULB & GLASS SHADE ..... 11
OPERATING THE REMOTE CONTROL/WALL CONTROL..... 12
CARE OF YOUR FAN..... 13
TROUBLESHOOTING..... 14
SPECIFICATIONS..... 15



minkaAire® A Minka Group® Co.
1151 W. Bradford Court, Corona, CA 92882 • For Customer Assistance Call: 1-800-307-3267
american lighting association
UL® LISTED E75795

1

# *SAFETY RULES*

1. Before you begin installing the fan, shut power off at the circuit breaker of the fuse box.
2. Be cautious! Read all instructions and safety information before installing your new fan. Review accompanying assembly diagrams.
3. Make sure that all electrical connections comply with local codes, ordinances, or National Electrical Codes. Hire a qualified electrician or consult a do-it-yourself wiring handbook if you are unfamiliar with installing electrical wiring.
4. Make sure the installation site you choose allows the fan blades to rotate without any obstructions. Allow a minimum clearance of 7 feet from the floor and 18 inches from the tip of the blades to the wall.
5. If you are mounting the fan to a ceiling fan outlet box, use a U.L. Listed metal octagonal outlet box marked "Acceptable for Fan Support". Secure the box directly to the building structure. The outlet box and its support must be able to support the moving weight of the fan (at least 50 pounds) Do not use a plastic box.
6. Caution: To reduce the risk of injury use only the screws provided with the outlet box in conjunction with the lock washers provided with the fan.
7. If you are mounting the fan to a joist, make sure it is able to support the moving weight of the fan (at least 50 pounds).
8. After you install the fan, make sure that all mounting components are secured to prevent the fan from falling.
9. Do not insert anything into the fan blades while the fan is operating.
10. To operate the reverse function on this fan, press the reverse button while the fan is running.

**ATTENTION:** **The Energy Policy Act of 2005 requires this fan to be equipped with a 190 watt limiting device. If lamping exceeds 190 watts, the ceiling fan's light kit will shut off automatically.**

**NOTE: The important safeguards and instructions appearing in this manual are not meant to cover all possible conditions and situations that may occur. It must be understood that common sense, caution and care are factors which can not be built into this product. These factors must be supplied by the person (s) installing, caring for and operating the unit.**

**NOTE: READ AND SAVE ALL INSTRUCTIONS!**

## WARNING

**TO REDUCE THE RISK OF FIRE, ELECTRIC SHOCK OR OTHER PERSONAL INJURY, MOUNT FAN ONLY TO A U.L. LISTED OUTLET BOX OR SUPPORTING SYSTEM MARKED ACCEPTABLE FOR FAN SUPPORT AND USE MOUNTING SCREWS PROVIDED WITH THE OUTLET BOX IN CONJUCTION WITH THE LOCK WASHERS PROVIDED WITH THE FAN. MOST OUTLET BOXES COMMONLY USED FOR FAN SUPPORT OF LIGHTING FIXTURES ARE NOT ACCEPTABLE FOR FAN SUPPORT AND NEED TO BE REPLACED. CONSULT A QUALIFIED ELECTRICIAN IF IN DOUBT.**

**TO REDUCE THE RISK OF PERSONAL INJURY, DO NOT BEND THE BLADE HOLDERS WHILE INSTALLING, BALANCING THE BLADES OR CLEANING THE FAN. DO NOT INSERT FOREIGN OBJECTS BETWEEN ROTATING FAN BLADES.**

**TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT USE THIS WITH ANY SOLID-STATE SPEED CONTROL DEVICE.**

# PACKAGE CONTENTS

Unpack your fan and check the contents. You should have the following items:

1. Fan blades (4)
2. Hanger bracket
3. Canopy
4. Canopy cover
5. Standard downrod ass'y
6. Minimum-length downrod
   (for close to the ceiling installation only)
7. Coupling cover
8. Fan motor/housing ass'y
9. Motor housing
10. Light plate
11. Glass Shade
12. 75W Mini-Can halogen bulb
13. Receiver (includes 6 wire nuts)
14a. Wall transmitter Incl. 2 mounting screws and 3 wire nuts
14b. Wall plate w/2 mounting screws
15. Extra Wall Plate w/2 Mounting screws
16. Balancing kit

A. Mounting hardware:
   #10 x 1.5" Wood screws (2 PCs.)
   #8 x 3/4" Machine screws (2 PCs.)
   Lock washers (2 PCs.)
   4mm Star washers (2 PCs.)
   Wire nuts (3 PCs. )
   Washers (2 PCs.)

B. Blade attachment hardware:
   3/16" x 7.5 mm screws (13 PCs.)
   Fiber washers (13 PCs.)









# INSTALLING THE FAN

**Tools Required: Phillips screw driver; slotted screw driver; step-ladder; wire cutters; electrical tape.**

## MOUNTING OPTIONS

**If there isn't an existing mounting box, then read the following instructions. Disconnect the power by removing fuses or turning off circuit breakers.**

**Secure the outlet box directly to the building structure. Use appropriate fasteners and building materials. The outlet box and its support must be able to fully support the moving weight of the fan (at least 50 lbs.). Use a UL Listed metal outlet box. Do not use a plastic outlet box.**

**Figure 1, 2 and 3 are examples of different ways to mount the outlet box.**

**Note:You may need a longer downrod to maintain proper blade clearance when installing on a steep, sloped ceiling. Longer downrods are available from your Minka-Aire® dealer.**

**To hang your fan where there is an existing fixture but no ceiling joist, you may need to install a hanger bar as shown in Fig. 4. (available at your Minka Aire® dealer or local hardware store)**



FIG. 1



FIG. 2



FIG. 3



FIG. 4

4

# *HANGING THE FAN*

WARNING: All of the parts, hardware and components such as the hanger bracket and hanger ball have been provided for your safety and the proper installation of your new ceiling fan. The use of other parts, hardware or components not supplied by Minka Aire® with the fan will void the Minka Aire® Warranty.

REMEMBER to turn off the power. Follow the steps below to hang your fan properly:

Step 1. Secure the hanger bracket to the ceiling outlet box using screws included with your outlet box, lock washers included with the fan. (Fig. 5)

Step 2. Loosen the two set screws and remove the hitch pin and lock pin in the top coupling of the motor assembly. (Fig. 6)

Step 3. Remove hanger ball from downrod assembly by loosening set screw, removing the cross pin, and sliding ball off rod. (Fig. 7)

Step 4. Carefully feed fan wires up through the downrod. (Fig. 8) Thread the rod into the coupling, next line up holes and replace lock pin and hitch pin. Tighten set screws.

Step 5. Slip coupling cover, canopy cover and canopy onto downrod. (Fig. 9) Carefully reinstall hanger ball onto rod being sure that cross pin is in correct position, set screws are tighten and wires are not twisted.

NOTE: DO NOT INSTALL THE COUPLING COVER IF YOU PLAN TO USE THE MINIMUM LENGTH DOWNROD.

Step 6. Now lift motor assembly into position and place hanger ball into hanger bracket. Rotate until the check groove has dropped into the registration slot and seats firmly. (Fig. 10) Rod should not rotate if this is done correctly.



Fig. 5



Fig. 6



Fig. 7



Fig. 8



Fig. 9



Fig. 10

# 5 ELECTRICAL CONNECTIONS

WARNING: To avoid possible electrical shock be sure electricity is turned off at the main fuse or breaker box before wiring.

NOTE: The Aire Control® System is equipped with a learning frequency function which has 256 code combinations to prevent potential interference from other remote units. The frequency on your Receiver and Transmitter units have been preset at the factory. (Fig. 11) No frequency change is necessary, should you desire to install another fan within the same home or area with a seperate frequency code please see the "frequency interference" troubleshooting section of this instruction manual to learn how to change the frequency.

Step 1. Insert Receiver into Hanger Bracket with the flat side of the Receiver facing the ceiling. (Fig. 12)

Step 2. Motor to Receiver Electrical Connections: Connect the WHITE wire from the fan to the WHITE wire marked "TO MOTOR N" from the Receiver. Connect the BLACK wire from the fan to the BLACK wire marked "TO MOTOR L" from the Receiver. Connect the BLUE wire from the fan to the BLUE wire marked "For Light" from the Receiver.

NOTE: If your ceiling fan features an UP Light: Connect the ORANGE wire from the fan to the ORANGE wire marked "For Up Light" from the Receiver. Otherwise disregard this step and proceed to secure all wire connections with the plastic wire nuts provided. (Fig. 13 & 14)

Note: Fan must be installed at a maximum distance of 40 feet from the transmitting unit for proper signal transmission between the transmitting unit and the fan's receiving unit.

**Step 3. Receiver to House Supply Wires Electrical Connections: Connect the WHITE wire (Neutral) from the outlet box to the WHITE wire marked "AC in N" from the receiver. Connect the BLACK wire (Hot) from the outlet box to the BLACK wire marked "AC in L" from the receiver. Secure all wire connections with the plastic wire nuts provided. (Fig. 13 & 14)**

**Step 4. If your outlet box has a GROUND wire (Green or Bare Copper) connect this wire to the Hanger Ball and Hanger Bracket Ground wires. If your outlet box does not have a Ground Wire, then connect the Hanger Ball and Hanger Bracket Ground Wires together. Secure wire connection with the plastic wire nut provided. (Fig. 13 & 14)**

**After all splices are made, check to make sure there are no loose strands. As an additional precaution we suggest to secure the plastic wire connectors to the wires with electrical tape.**



Fig. 11




Fig. 12


OUTLET BOX
BLACK (HOT)
WHITE (NEUTRAL)
GREEN OR BARE COPPER (GROUND)
BLACK ("AC IN L")
WHITE ("AC IN N")
RECEIVER
BLACK ("TO MOTOR L")
WHITE ("TO MOTOR N")
BLUE (FOR LIGHT)
ORANGE (FOR UPPER LIGHT)
GROUND (GREEN)
(CONNECT TO GROUND WIRE ON HANGER BRACKE IF NO HOUSE GROUND WIRE EXISTS.)
BLUE (FOR LIGHT)
BLACK (MOTOR)
ORANGE (FOR UPPER LIGHT)
WHITE (NEUTRAL)

Fig. 13


AC120V
INPUT
WHITE
AC SUPPLY
BLACK
BLACK
WHITE
WALL CONTROL
GREEN
GROUND
BLACK
BLACK
BLACK
BLACK
BLUE
BLACK
WHITE
ORANGE
BLUE
BLACK
WHITE
ORANGE
GROUND
GREEN

Fig. 14

# *INSTALLING THE WALL TRANSMITTER*

WARNING! HOOK UP "IN SERIES" ONLY. DO NOT CONNECT NEUTRAL SUPPLY WIRE OF ELECTRIC CIRCUIT TO THE TRANSMITTER WALL SWITCH, DAMAGE TO THE TRANSMITTER WALL SWITCH AND POSSIBLE FIRE COULD OCCUR.

Step 1. Remove the existing wall plate and switch from the wall outlet box.

Step 2. Make the electrical connections as shown in Fig.14. If your outlet box has a ground wire (Green or Bare Copper) connect the Transmitter's ground wire directly to one of the screws from the outlet box. Secure all wire connections with the plastic wire nuts provided.

Step 3. Carefully tuck the wire connections inside the outlet box. Use the screws provided to secure the wall transmitter and wall plate to the outlet box. (Fig. 15)

NOTE: Your Aire Control® System includes two sets of face and decorative plate color options. The wall control comes with standard white faceplate attached. If you desire to replace it with the Ivory color faceplate included, use a small flat screw driver and gently pry it apart from the top or bottom of the plate.



Fig. 15

7

# *FINISHING THE INSTALLATION*

Step 1. Slide the canopy up to the ceiling and over the two screws on hanger bracket. Rotate canopy clockwise, next, while holding the canopy with one hand, slide the canopy cover over the screws and rotate clockwise until tight. (Fig. 16)

Note: Adjust the canopy screws as necessary until the canopy and canopy cover are snug.




Fig. 16

# BLADE INSTALLATION

8

**Step 1. Attach the fan blade to the blade holder using the screws and fiber washers provided. Tighten screws securely. Repeat process for remaining blades.(Fig. 17)**




Fig 17

9

# *INSTALLING THE MOTOR HOUSING*

1. **Remove 1 of 3 screws from the mounting ring and loosen the other 2 screws. (Do not remove)**

2. **Place the key holes from the motor housing over the 2 screws previously loosened from the mounting ring, turn motor housing until it locks in place at the narrow section of the key holes. Secure by tightening the 2 screws previously loosened and the one previously removed. (Fig. 18)**




Fig. 18

# *INSTALLING THE LIGHT PLATE*

**NOTE: Before starting installation, disconnect the power by turning off the circuit breaker or removing the fuse at fuse box.**

1. **Remove 1 of 3 screws from the motor housing and loosen the other 2 screws. (Do not remove)**

2. **Raise and hold the light plate close to the motor housing and proceed to do the wire connections. Connect the white wire connectors from the light plate and fan, follow the same procedure with the black wire connector from the fan and the black wire connector from the light kit. (Fig. 19)**

3. **Place the key holes from the light plate over the 2 screws previously loosened from the motor housing, turn light plate until it locks in place at the narrow section of the key holes. Secure by tightening the 2 screws previously loosened and the one previously removed. (Fig. 19)**




Fig. 19

11

# *INSTALLING THE LIGHT BULB & GLASS SHADE*

**WARNING: Shut of the power supply before removing or replacing lamp. In handling of halogen bulb, care should be taken not to touch it with your bare hands. Oil residue will shorten the life of the halogen bulb. If you accidentally come into contact, wipe thoroughly with a clean, lint-free, cotton cloth. Allow the bulb to cool off for 10 minutes before changing the bulb. Use light bulb in accordance with the fan's specification. TO REDUCE THE RISK OF FIRE DO NOT EXCEED MAXIMUM WATTAGE RATING.**

**ATTENTION: The Energy Policy Act of 2005 requires this fan to be equipped with a 190 watt limiting device. If lamping exceeds 190 watts, the ceiling fan's light kit will shut off automatically.**

**Step 1. Install 1x75W halogen bulb (included) into bulb socket.**

**Step 2. Raise glass shade up against bottom of fan housing and secure it to fan by turning it clockwise until snug. DO NOT OVERTIGHTEN. (Fig. 20)**



Fig. 20

# OPERATING THE REMOTE CONTROL/WALL CONTROL

**Remote Control only: Install a A23 12 volt battery (included). To prevent damage to transmitter remove the battery if not used for long periods of time.**

Restore Power to Ceiling Fan.

A. ● ● ● Buttons:
These buttons are used to set the fan speeds as follows;
● = Low Speed
● ● = Medium Speed
● ● ● = High Speed

B. ■ Button:
This button turns the fan off.

C. Button:
These buttons turn the light ON or OFF and also control the brightness settings of the light. The following instructions apply to ceiling fans that feature a DOWN light ( button) only or ceiling fans that feature an UP light ( button) and a DOWN light ( button) that are controlled independent of each other;

Press and release the button for the desired light to turn the light ON or OFF. Press and hold the button to set the desired light brightness. The light will cycle between bright and dim settings as long as the button is pressed. The light key has an automatic auto-resume feature that allows the light to remain at the same brightness as the last time it was turned off.

D. OFF-ON Slide Button (Wall Control Fans Only)
This button turns the power Off and On to the Fan and Light(s).

E. Button: (Full Function Remote Control Units Only)
This button is used to change the direction of the rotation of the blades; forward for warm weather or reverse for warm weather.

NOTE: If your Remote Control or Wall Control does not have a " " button, Please look for a slide reverse switch on the motor housing.

**Speed settings for warm or cold weather depend on factors such as room size, ceiling height and number of fans.**

**NOTE: To operate the reverse function on this fan, press the reverse button while the fan is running.**

**Warm Weather (forward)**
**A DOWNWARD airflow creates a cooling effect as shown in Figure 21. This allows you to set your air conditioner on a warmer setting without affecting your comfort.**

**Cool Weather (Reverse)**
**An UPWARD airflow moves warmer air off the ceiling area as shown in Figure 22. This allows you to set your heating unit on a cooler setting without affecting your comfort.**



Fig 21



Fig 22

# CARE OF YOUR FAN



**Here are some suggestions to help maintain your fan.**

**1. Because of the fan's natural movement some connections may become loose. Check the support connections, brackets and blade attachments twice a year. Make sure they are secure. (It is not necessary to remove fan from the ceiling).**

**2. Clean your fan periodically to help maintain its new appearance over the years. Use only a soft brush or lint free cloth to avoid scratching the finish. Plated finishes are sealed with lacquer to minimize discoloration or tarnishing. Do not use water when cleaning, this could damage the motor, wood blades or possibly cause an electrical shock.**

**3. Use a lint free lightly damp cloth or duster to remove dust from the blades.**

**4. There is no need to oil your fan. The motor has permanently lubricated bearings.**

**5. If your fan is provided with glass shades, clean with lukewarm soapy water and a soft cloth or sponge. DO NOT IMMERSE GLASS SHADES IN HOT WATER. DO NOT PUT GLASS SHADES INTO AN AUTOMATIC DISHWASHER.**

**WARNING!**
**MAKE SURE THE POWER IS OFF AT THE ELECTRICAL PANEL BOX BEFORE YOU ATTEMPT ANY REPAIRS. REFER TO THE SECTION, "ELECTRICAL CONNECTIONS".**

14

# *TROUBLESHOOTING*

**SYMPTOM**
**Fan will not start**

**SOLUTION**

- **Check to make sure the wall switch is turned on.**
- **Check circuit fuses or breakers.**
- **Caution! Make sure the power is turned off before performing the following steps.**
- **Remove canopy and check wire connections.**
- **Check wall control transmitter connections (if applicable).**
- **Note: Fan must be installed at a maximum distance of 40 feet from the transmitting unit for proper signal transmission between the transmitting unit and the fan's receiving unit.**

**SYMPTOM**
**Fan Sounds Noisy**

**SOLUTION**

- **Allow a 24-hour "break in" period. Most noises associated with a new fan will go away during this time.**
- **Make sure the screws that attach the fan blade holder to the motor hub is tight.**
- **Make sure outlet box is secured to building structure, if necessary use the wood screws provided to further secure outlet box to joist.**
- **Make sure hanger bracket is secure to the outlet box, screws are tight.**

SYMPTOM
Fan Wobble

SOLUTION

- NOTE: All blade sets are grouped by weight. Because wood and plastic blades vary in density, the fan may wobble even though blades are matched.
- Make sure outlet box is secured to building structure, if necessary use the wood screws provided to further secure outlet box to joist.
- Make sure hanger bracket is secure to the outlet box, screws are tight.
- Use the balancing kit provided if the wobble is excessive (follow instructions included with balancing kit)

SYMPTOM
Lights shut off and will not come back on.

SOLUTION

- This unit is equipped with a wattage limiting device. Lamping in excess of 190 watts will disable your ceiling fan's light kit. To reset your light kit you must turn the power off and re lamp, keeping the wattage under 190 watts. Restore power to your ceiling fan and continue normal operation.

SYMPTOM
Fans/Light Turn On and Off Unexpectedly

SOLUTION

- This is caused by interference, Please see "Frequency interference" for steps to change the frequency.

**SYMPTOM**
**Frequency Interference**
**SOLUTION**

1. **Turn the power off to your ceiling fan.**

2. **Please use a small size tool to change the frequency settings on the control system.**

3. **Return power to the unit.**
   **Note: After the AC power is on, do not press any other button on the transmitter before pressing the "Stop" button, doing so will cause the procedure to fail.**

4. **Within 60 seconds of turning the Fan's AC power ON. Press the transmitter's "Stop" button and hold the "Stop¡" button for 10 seconds.**

5. **Once the receiver has detected the set frequency, the down light of your fan if applicable will blink twice. (there is no indication if your fan is not equipped with a light).**

6. **The receiver has now learn the frequency which has been selected on the transmitter. After completing the steps above, you should be able to operate the ceiling fan and light. If the fan is not responding to the transmitter, please turn the power off to the receiver, and repeat the process.**

# *SPECIFICATIONS*

**These are typical readings. Your actual fan may vary. They do not include amps and wattage used by the light(s).**

| Fan Size | Speed | Volts | Amps | Watts | RPM | CFM | N.W. | G.W. | C.F. |
|---|---|---|---|---|---|---|---|---|---|
| 56" | Low | 120 | 0.35 | 17 | 70 | 2428 | 9.12 kgs | 10.33 kgs | 1,89' |
| | Medium | 120 | 0.49 | 42 | 110 | 3876 | | | |
| | High | 120 | 0.53 | 62 | 140 | 4649 | | | |

***For any additional information about your Minka Aire® Ceiling fan, please write to;***

minkaAire® A Minka Group® Co. **1151 W. Bradford Court, Corona, CA 92882 • For Customer Assistance Call: 1-800-307-3267**